

Acoustica Standard Edition 5

User Guide

Acon Digital Media GmbH

Acoustica User Guide

Copyright © 2003-2010 Acon Digital Media GmbH

All rights reserved. No parts of this work may be reproduced in any form or by any means - graphic, electronic, or mechanical, including photocopying, recording, taping, or information storage and retrieval systems - without the written permission of the publisher.

Products that are referred to in this document may be either trademarks and/or registered trademarks of the respective owners. The publisher and the author make no claim to these trademarks.

While every precaution has been taken in the preparation of this document, the publisher and the author assume no responsibility for errors or omissions, or for damages resulting from the use of information contained in this document or from the use of programs and source code that may accompany it. In no event shall the publisher and the author be liable for any loss of profit or any other commercial damage caused or alleged to have been caused directly or indirectly by this document.

Table of Contents

Part I Introduction	4
1 What is new in Acoustica Standard Edition 5.0	4
2 Requirements	5
Part II Basic Audio Editing	5
1 The Acoustica Workspace	5
2 Loading Audio Files	7
3 Saving Audio Files	7
4 Playing a Recording	7
5 Selecting Regions	8
6 Selecting Channels	8
7 Zooming and Scrolling	8
8 Drag and Drop Editing	9
9 Editing using the Clipboard	10
10 Audio Scrubbing	11
11 Labels and Regions	11
12 Adding Loops for MIDI Samplers	13
13 Using Analyzers	14
Level Meter	14
FFT Analyzer	15
Phase Correlation Meter	15
Big Time Display	16
Part III Connecting Your Stereo Equipment	16
1 Connecting a Tape Deck (Cassette Tape)	16
2 Connecting a Record Player (LP)	18
Connecting a Record Player through an Amplifier	19
Connecting a Record Player Directly	20
Part IV Recording	23
1 Concepts of Digital Audio	23
Sampling	24
Quantization	24
The Decibel Unit (dB)	25
2 Recording through the Sound Card	25
Timer Record	27
Advanced Recording Options	28
Part V Audio Processing	28
1 Manipulating Volume	30

Adjusting the Volume	30
Normalize	30
Applying a Volume Curve	31
Fading In or Out	32
The Channel Mixer	32
2 Audio Effects	33
Dynamic Processor	33
Limiter	35
Echo	36
Reverb	37
Convolution Reverb	37
Flanger	38
Chorus	39
Distortion	40
Harmonizer	41
Transpose	42
Time Stretching	44
Reverse	45
3 Using Audio Plug-Ins	45
Refreshing the Plug-in List	45
Specifying VST Directories	45
4 Noise Reduction	46
Automatic Noise Reduction	46
Removing Noise with a Measured Profile	47
Removing Noise with a User Drawn Profile	48
Automated Click Removal	49
Manual Click Removal	50
5 Enhancement Tools	50
Declipper	50
Equalizer	51
High Frequency Rebirth	53
Stereo Enhancer	54
Remove DC Offset	54
Phono Filter	54
6 Converting the Sample Format	55
7 Effect Chains	56
 Part VI Working with Audio CDs	 57
1 Creating Audio CDs	57
Adding an Existing Audio File	58
Adding the Content of an Editing Window	58
Burning the CD	58
2 Importing Audio Tracks from CDs	59
 Part VII Using the Cleaning Wizard	 61
1 The Import Page	61
Record Audio	62
Import Files	63
2 The Restoration Page	64
Track Splitting	64

Restoration	65
Further Editing and Processing	66
3 The Export Page	67
Burn a CD	67
Export to Audio Files	68
 Part VIII Using the Batch Processing Wizard	 68
1 Adding Source Files	69
Importing Folders	69
Creating Folders	70
Removing an Item	70
2 The Target Files Page	71
Adding Processing Tools	71
Defining File and Sample Format	72
Specifying the Target Folder	73
 Part IX Audio Analysis	 73
1 Time Domain	73
2 Frequency Domain	73
3 Combining Time and Frequency	74
 Part X Preferences and Device Settings	 75
1 Device Settings	75
2 Changing the Preferences	75
The Directories Page	76
 Index	 77

1 Introduction

Acoustica is a comprehensive solution for professional audio recording, editing and mastering. The intuitive user interface was designed with speed, accuracy and ease-of-use in mind and gives access to a large set of powerful tools to make your recordings sound the best. The consistent workflow simplifies your production work all the way from recording, editing, batch processing, sound design and audio restoration to Red Book compatible CD burning.

1.1 What is new in Acoustica Standard Edition 5.0

Acoustica Standard Edition 5 contains several exciting new features. The highlights are:

Graphical user interface

- New audio plug-in design
- Tabbed MDI interface
- Dockable file browser pane

New file formats

- FLAC
- AAC

CD Cover Editor

Makes the creation of CD covers from your CD projects a breeze

CD Projects

- Save and open CD projects
- Erase CD-RWs

K-System metering

The new K-System level meters help you to produce consistent sounding music while preserving appropriate dynamic range.

Enhanced spectrum analysis

The updated offline analysis tools allow you to select frequency and amplitude ranges. The spectrum analysis now allows logarithmic frequency scales and can show the average spectrum over a large time selection.

Convolution reverb

Simulate the reverberation of physical or virtual spaces based on pre-recorded impulse responses.

Test signal generator

- White, pink and brownian noise
- Sine tones
- Chirps

1.2 Requirements

Before you install Acoustica Standard Edition, please make sure your computer fulfills the following requirements:


- A computer running Windows 7, Windows Vista or Windows XP
- Pentium IV or higher
- Minimum 256 MB RAM (1 GB recommended)
- Minimum 16 bit color depth
- Windows compatible sound card

2 Basic Audio Editing

This chapter describes the basic audio editing capabilities of Acoustica such as loading and saving files and editing using the clipboard or drag and drop.

2.1 The Acoustica Workspace

The Acoustica workspace can contain several audio editing windows, CD projects or Cleaning Wizard projects.



The Acoustica workspace

The figure above shows the Acoustica workspace with an audio editing window and a CD project. The elements indicated with the red arrows are explained below:

1. The main toolbar with short cut icons for commonly used commands.
2. The navigation toolbar for recording, playback and cursor positioning.
3. An audio editing window containing the audio file "Matecha.wav". The audio is visualized with a curve corresponding to the recorded audio (see [Time Domain](#)).
4. A selected region indicated with white curve on a blue background (colors depend on your system settings). The current cursor position is indicated by a blinking line.
5. The output level meters show the current output level during audio playback.
6. The status bar indicating the selected region, the viewed region and the cursor position. During processing, the progress is displayed in the status bar.
7. A "CD project" window containing a list of tracks and a toolbar for commands relevant to CD recording.
8. The list of CD tracks that are about to be recorded to an audio CD.

2.2 Loading Audio Files

To open existing audio file,

1. Select from the *File* menu the command *Open...*
2. Choose the folder in which your file is located from the *Look in* drop-down list.
3. Click the audio file you wish to open and click the button labelled *Ok*.

2.3 Saving Audio Files

To save an edited audio file with its original name:

1. Select from the *File* menu the command *Save* or press Ctrl+S.

If you wish to save the content of an audio editing window with a different name, in a different folder or with different settings:

1. Select from the *File* menu the command *Save as...*
2. Choose the folder in which you wish to save the file from the *Look in* drop-down list.
3. Enter a name for your audio file.
4. Choose the file format of your audio file from the *File type* drop-down list.
5. Most export filters offer different settings such as encoding bit rate or number format. To change the settings, click the button labelled *Options...*

2.4 Playing a Recording

To play the selected region of a recording:

1. Select from the *Sound* menu the command *Play* or press the space bar.
2. You can stop the playback by selecting from the *Sound* menu the command *Stop* or by pressing the space bar.

You can also play the complete recording:

1. Select from the *Sound* menu the command *Play all* or hold the shift key while pressing the space bar.
2. You can stop the playback by selecting from the *Sound* menu the command *Stop* or by pressing the space bar.

To play the selected region as a loop:

1. Select from the *Sound* menu the command *Play looped* or hold the control key while pressing the space bar.
2. You can stop the playback by selecting from the *Sound* menu the command *Stop* or by pressing the space bar.

Alternatively, you can use the navigation toolbar for convenient playback:



The navigation toolbar with the logic similar to consumer audio equipment such as CD players or tape decks.


2.5 Selecting Regions

Acoustica does all processing on the selected region and the selected channels only. The selected region is highlighted. To change the selected region:

1. Click the beginning of the region you wish to select and keep the mouse button down.
2. Move the mouse cursor to the end of the region you wish to select while keeping the mouse button down.
3. Release the mouse button.
4. The newly selected region should now be highlighted.

2.6 Selecting Channels

Acoustica does all processing only on the selected region and the selected channels. To change the selected channel or channels (only possible with stereo recordings):

1. Click the channel selection button in the main toolbar (see [The Acoustica Workspace](#)): .
2. A drop-down list with the channels appears.
3. Click the channel you wish to activate or deactivate.

2.7 Zooming and Scrolling

You can zoom in to get a more detailed view in an editing window. You can zoom either horizontally to view a smaller part of the recording or vertically to show a smaller amplitude range.

Horizontal zoom

To zoom in horizontally:

- Press the arrow up key

- or -

- Move the mouse wheel upwards

To zoom out for a better overview:

- Press the arrow down key

- or -

- Move the mouse wheel downwards

Note You can zoom out to view the whole recording by selecting View | View all or by pressing Shift + A.

Scrolling

In those cases where only a part of the recording is shown, a scroll bar is visible below the visualisation of the wave form. You can use the scroll bar to view other parts of the recording.

Vertical zoom

To zoom in vertically:

- Press and hold the control key while pressing the arrow up key

To zoom out vertically:

- Press and hold the control key while pressing the arrow down key

You can also enter the zoom factor in the toolbar and press the enter key:



The vertical zoom bar

2.8 Drag and Drop Editing

You can move or copy regions using so-called drag and drop editing. To move a region to a another location in the same editing window or to another editing window:

1. Select the region you wish to move (see [Selecting Regions](#)).

2. Click the somewhere within the highlighted region and keep the mouse button down.
3. Press the *Shift* key while moving the mouse cursor to the new start position and release the mouse button.

To insert a copy of a region using drag and drop:

1. Select the region you wish to copy (see [Selecting Regions](#)).
2. Click the somewhere within the highlighted region and keep the mouse button down.
3. Press the *Ctrl* key while moving the mouse cursor to the insert position and release the mouse button.

To mix two regions using drag and drop:

1. Select the first of the regions you wish to mix (see [Selecting Regions](#)).
2. Click the somewhere within the highlighted region and keep the mouse button down.
3. Press the *Alt* key while moving the mouse cursor to the start position and release the mouse button.

Note If you press neither the *Ctrl* key nor the *Shift* key during drag and drop, Acoustica will perform the default action which is a move operation if the drop destination is the same editing window and a copy operation if the drop destination is another editing window.

2.9 Editing using the Clipboard

The clipboard concept provides a common way of editing documents for all Windows applications. You can edit your recordings by copying the selected region to the Acoustica clipboard using the command *Edit | Copy* and paste the region into another location using the command *Edit | Paste Insert*. The *Paste Insert* command is equivalent to the normal paste command common in most Window applications. Acoustica has offers two additional ways of pasting:

- Paste Overwrite, which substitutes a selected region with the content of the clipboard.
- Paste Mix, which mixes the selected region with the content of the clipboard.



The command *Edit | Cut* copies the selected region to the clipboard before deleting it from the source recording. For the purpose of deleting parts of the recording, use one of

the following two commands:

- Delete, which deletes the selected region
- Crop, which deletes everything but the selected region.

2.10 Audio Scrubbing

Sometimes it is hard to find a specific part of a recording using the visualization only. The audio scrub mode simplifies the search by giving aural feedback while you can move the playback position using the mouse. To use the audio scrubbing:

1. Enable the audio scrubbing mode clicking the audio scrubbing symbol in the toolbar () or by pressing A.
2. Click the left mouse button and keep it down while moving the mouse cursor
3. Release the mouse button when you have found the part you were searching for.
4. Enable the selection mode by clicking the selection mode symbol in the toolbar () or by pressing S.

2.11 Labels and Regions

You can simplify the editing process by inserting anchors such as labels and regions to your recording.

Adding Labels

To add a label to the recording:

1. Move the cursor position to where you want to insert a label
2. Click the right mouse button and select "Add Label..." or press L.
3. A label appears at the cursor position

Note You can press Ctrl + L to add a new label and directly open a dialog box to give it a name.

Adding Region Markers

To add a region marker to the recording:

1. Select the part of the recording where you want a region marker
2. Click the right mouse button and select "Add Region..." or press R.
3. A region is appears at the selection

Note You can press Ctrl + R to add a new label and directly open a dialog box to give it a name.

Renaming, Moving and Deleting Anchors

You can easily rename anchors:

1. Double click the anchor text
2. A properties dialog box appears.
3. Enter the new name of the anchor.
4. Click the button labelled OK.

You can also move the anchors:

1. Click the left mouse button at the upper part of red line visualizing the anchor.
2. Keep the mouse button down while moving the anchor to its new position
3. Release the mouse button.

To delete an anchor:

1. Click the right mouse button at the anchor text
2. A context menu appears.
3. Select "Delete"

The Label and Region List Windows


You can edit and keep track of your anchors by showing the region list and label list windows. To show the label list window, select "Label List" from the View menu. The menu item "Region List" from the same menu shows the region list.

Label List			Region List		
Name	Position		Name	Begin	End
Hit	00:02:21:120		Intro	00:00:00:000	00:00:27:157
Ending	00:02:51:671		Part A	00:00:27:157	00:01:05:225
			Chorus	00:01:05:225	00:02:00:267

The Region and Label List windows make it easy to edit and keep track of the anchors.

2.12 Adding Loops for MIDI Samplers

Audio files in the WAVE format can contain specialized loop information for MIDI Samplers and software samplers. Acoustica supports this standard and you can add loops and define the base note and fine tuning of the recorded sample. To add a sample loop, selected *Edit | Add Sampler Loop...* or press "O". The *Add Sampler Loop* dialog box appears:



The Add Sampler Loop dialog box.

You can specify an infinite loop that is repeated until the MIDI note is released or a specific loop count. Acoustica also allows you to crossfade the ending and the beginning of the loop to avoid click sounds at the loop edge. Add a check mark to the *Enable Crossfading* check box to enable the cross fading. You can specify the percentage of the loop duration that is used for cross fading.


The information in *Global MIDI Sample Settings* is not stored for each loop, but are global settings for the complete recording. You can edit these settings when adding loop, because loop and note with fine tuning information is usually required when creating loops for MIDI samplers. However, you can also change these parameters in the *Tempo and Key* tab of the recording properties (*File | Edit Properties...*).

2.13 Using Analyzers

The integrated analyzers allow you to analyze the output audio signal in real time during playback. You can hide or show the analyzers by choosing *View | Analyzers* and selecting one of the analyzers from the sub menu.


2.13.1 Level Meter

The *level meter* lets you analyze the output level in terms of peak, peak hold and RMS values. The peak value is the maximum sample within a short analysis interval and is the value defining the height of the level meter bars. The peak hold value is the maximum sample level over a longer period of time. It is indicated as a white line above or at the top of the level meter bar. RMS stands for root-mean-square and is calculated by the root of the sum of the squared sample values during the analysis interval.



The level meter analyzer showing the peak hold value (1), peak value (2) and RMS value (3).

You can configure the level meter to use different scales or change ballistics by clicking the left mouse button somewhere in the level meter. The following dialog box appears:




The settings dialog for the level meters.

Acoustica supports the K-System metering standard proposed by the audio engineer Bob Katz. The K-System is an attempt to standardize leveling practices throughout the audio industry. Three standards are available, K-20, K-14, and K-12 which are intended for different listening environments. You can choose to use one of the K-System meters or use the digital full scale meter as in earlier version of Acoustica.

2.13.2 FFT Analyzer


The *FFT Analyzer* shows the frequency content of short analysis time frames. FFT stands for Fast Fourier Transform. FFT is an efficient way of calculating the frequency domain of a signal. For more information about the frequency domain, please see [Frequency Domain](#).



The FFT Analyzer shows the frequency content of the output audio signal.

2.13.3 Phase Correlation Meter

The *phase correlation meter* shows the phase relationship between the left and the right audio channel in a stereo recording and is an important tool when mastering stereo recordings. If both channels contain exactly the same signal, the phase correlation meter will show a vertical line. If one channel is exactly the opposite of the other channel, the phase correlation meter shows a horizontal line. Normal stereo recordings will show a cloud of dots spread out vertically and horizontally (see the picture below). In a properly mastered recording, the cloud of dots should not be wider than it is tall.



The phase correlation meter shows the relationship between the left and the right channel in a stereo recording.

2.13.4 Big Time Display


The big time display shows the current playback position in a resizable and dockable window.

3 Connecting Your Stereo Equipment

This chapter describes how to connect your tape deck (cassette tape player) or your record player to your computer.


3.1 Connecting a Tape Deck (Cassette Tape)

If you have an external tape deck or a compact stereo system, it will probably have so called "RCA connectors" on the backside labelled *Line Out*, *Tape Out* or *Tape Rec*, as depicted below:



RCA connectors on a tape deck unit. Connect the sound card to the Line Out connector (1).

The *Line Out* of the tape deck or stereo system will now need to be connected to the computer. Integrated sound cards are usually equipped with "mini jack" connectors (also called 3,5 mm jack).



The back pane of a computer with an integrated sound card and a line in mini jack connector (1).

Connecting to a Sound Card with Mini Jack Connector


If your computer has mini jack connectors, a connection cable with a mini jack connector on one end and RCA connectors on the other end is required to connect your tape deck or stereo system to your computer.



A connection cable with RCA connectors on one end and a mini jack connector on the other.


If you didn't receive such a cable with your sound card or computer, you can purchase one in normal audio or electronics stores.

To connect your tape deck or stereo system, connect the end with the RCA connectors to the *Line Out*, *Tape Out* or *Tape Rec* connectors on your tape deck or stereo system.

Connect the other end to the *Line In* connector of your computer. The *Line In* connector is either labelled as such or indicated with the following symbol: .

Connecting to a Sound Card or USB Audio Device with RCA connectors

External USB devices for audio input and output are growing in popularity and many of these have normal *Line In* RCA connectors. In rare cases, internal sound cards might also have RCA connectors. In these cases, a connection cable with RCA connectors on both ends is required.




A connection cable with RCA connectors on both ends.

You can purchase RCA connection cables in normal audio or electronics stores if you don't have one already. In this case, all you have to do is connect the cable to the *Line Out*, *Tape Out* or *Tape Rec* connectors on your tape deck or stereo system and the *Line In* connectors of the sound card.

3.2 Connecting a Record Player (LP)

If you have a stereo system with an amplifier already set-up, the easiest way to connect a record player to your computer is to connect the computer to the amplifier's *Line Out* connectors (sometimes also labelled *Tape Out*, *Tape Rec* or *Rec Out*).



RCA connectors on an amplifier. Make sure the record player is properly connected to the phono input (1) and connect the sound card to the Rec Out connector (2).

3.2.1 Connecting a Record Player through an Amplifier

Before you proceed, please make sure your record player is properly connected to your amplifier and that you can listen to records on your stereo system.

The *Line Out* of the amplifier or stereo system will now need to be connected to the computer. Integrated sound cards are usually equipped with "mini jack" connectors (also called 3,5 mm jack).



The back pane of a computer with an integrated sound card and a line in mini jack connector (1).


Connecting to a Sound Card with Mini Jack Connector

If your computer has mini jack connectors, a connection cable with a mini jack connector on one end and RCA connectors on the other end is required to connect your amplifier or stereo system to your computer.




A connection cable with RCA connectors on one end and a mini jack connector on the other.

If you didn't receive such a cable with your sound card or computer, you can purchase one in normal audio or electronics stores.

To connect your amplifier or stereo system, connect the end with the RCA connectors to the *Line Out*, *Tape Out* or *Tape Rec* connectors on your amplifier. Connect the other end to the *Line In* connector of your computer. The *Line In* connector is either labelled as such or indicated with the following symbol: .

Connecting to a Sound Card or USB Audio Device with RCA connectors

External USB devices for audio input and output are growing in popularity and many of these have normal *Line In* RCA connectors. In rare cases, internal sound cards might also have RCA connectors. In these cases, a connection cable with RCA connectors on both ends is required.



A connection cable with RCA connectors on both ends.

You can purchase RCA connection cables in normal audio or electronics stores if you don't have one already. In this case, all you have to do is connect the cable to the *Line Out*, *Tape Out* or *Tape Rec* connectors on your amplifier or stereo system and the *Line In* connectors of the USB audio device.


3.2.2 Connecting a Record Player Directly

It is usually not possible to connect a record player directly to the computer, because the audio on LP records is modified for technical reasons so that low frequencies (bass) are too soft and high frequencies (treble) too loud. Amplifiers with a phono input modify the signal using an exactly tuned equalizer so that the original signal is restored. It is also possible to purchase hardware units solely for this purpose. These are usually called phono preamplifiers.

The good news is that you with Acoustica 4 probably don't need any additional hardware. Acoustica 4 emulates the equalizer in phono preamplifiers and thus restores the original audio. You can connect the record player directly to the *Line In* on your sound card and enable the *Emulate phono preamplifier* option in the recording page (see

[Record Audio](#) for more information).

In most cases, the record player will have "RCA connectors" on the backside labelled *Phono*, as depicted below:



RCA connectors on a record player.

Some record players come with a fixed cable with male RCA connectors:



Cable with male RCA connectors.

The output from your record player will now need to be connected to the computer. Integrated sound cards are usually equipped with "mini jack" connectors (also called 3,5 mm jack).



The back pane of a computer with an integrated sound card and a line in mini jack connector (1).

Connecting to a Sound Card with Mini Jack Connector


If your computer has mini jack connectors and your record player female RCA connectors, a connection cable with a mini jack connector on one end and RCA

connectors on the other end is required to connect your record player to your computer.




A connection cable with RCA connectors on one end and a mini jack connector on the other.

If you didn't receive such a cable with your sound card or computer, you can purchase one in normal audio or electronics stores.

To connect your record player, connect the end with the RCA connectors to the *Phono Out* connectors on your record player. Connect the other end to the *Line In* connector of your computer. The *Line In* connector is either labelled as such or indicated with the following symbol: .

If your record player has an integrated cable with male RCA connectors you will need an RCA to mini jack adapter (available in audio or electronic stores), as depicted below:




An RCA to mini jack adapter.

The mini jack end of the adapter can be connected to the *Line In* connector of the sound card as already described.

Connecting to a Sound Card or USB Audio Device with RCA connectors

External USB devices for audio input and output are growing in popularity and many of

these have normal *Line In* RCA connectors. In rare cases, internal sound cards might also have RCA connectors. In these cases, a connection cable with RCA connectors on both ends is required if the record player doesn't have a cable with male RCA connectors attached.



A connection cable with RCA connectors on both ends.

You can purchase RCA connection cables in normal audio or electronics stores if you don't have one already. In this case, all you have to do is connect the cable to the *Phono* connectors on your record player and the *Line In* connectors of the USB audio device.

4 Recording

Recording audio in Acoustica is easy, but there are some terms you should know before starting your first recording project. The chapter [Concepts of Digital Audio](#) theoretically describes some important issues regarding digital audio. If you are familiar with digital audio, please proceed to [Recording through the Sound Card](#).

4.1 Concepts of Digital Audio

Before audio can be edited on computers it must be digitized. The output from most audio equipment such as tape recorders, microphones or record players is analog. Analog means that the audio signal is represented by an alternating electrical voltage. The voltage is analog to the air pressure changes in the air during the performance, hence the term analog signals. The sound card in your computer is needed to convert the constantly changing electrical voltage to a stream of numbers at fixed rate intervals. This process is done in two steps called *sampling* and *quantization*.


4.1.1 Sampling

The conversion from a continuously changing measure to a series of measured values at discrete time instances is called sampling. The rate (or number of measurements per second) of which the sampling is done, is along with the quantization depth the most important quality factor of digital recording equipment. If it is set too low, disturbing artifacts occur. A CD quality recording is recorded with a sampling rate of 44 100 samples per second. We say that the *sampling frequency* is 44 100 Hertz (or short Hz).

In fact, all frequencies above half the sampling frequency, which is known as the Nyquist frequency, are substituted by frequencies below the Nyquist frequency. This effect is called aliasing. To avoid aliasing a sampling system contains of a low pass filter which ideally filters out all frequencies above the Nyquist frequency and leaves all frequencies below unaffected. In the case of the audio CD, the highest frequency that can theoretically be recorded is 22 050 Hz.

4.1.2 Quantization

After measuring an analog input signal at fixed time intervals we have a stream of samples. The samples exist in terms of a voltage measured at a certain point in time. The voltage can usually be one of an infinite number of possible voltages within the legal voltage range. Computers cannot accurately describe every single one of the infinite number of possibilities, so it is necessary to divide the voltage range of interest into fixed sized regions. All voltages within one region are given a certain number during the quantization process. If we have a large number of regions which implies a larger number of discrete voltage levels, we can describe a voltage more accurately than with fewer voltage levels. The audio CD is quantized with 65536 voltage levels, which is the maximum number of levels possible to archive with a binary number with 16 bits. Thus we say that the Audio CD has 16 bit resolution. Modern recording studios are frequently using 24 bit resolution or even higher during the mastering process.




The digital representation of a sine wave.

4.1.3 The Decibel Unit (dB)

When the volume of the recorded sound is changed, the degree of change is usually expressed in terms of decibels or short dB. This is a common unit in connection with audio. In Acoustica, decibel is used to express the extent of change relative to the original level.

Special for the decibel unit is that it is based on a logarithmic scale. Zero dB represents no change, whereas an increase of six dB represents a doubling of the signal amplitude. Reducing by six dB results in half the signal amplitude.




The decibel dB versus intensity change in percent

The decibel scale is chosen to suit the sensitivity curve of the human ear which have the same logarithmic property.

4.2 Recording through the Sound Card

Please follow the steps below to record audio from audio equipment such as record players, tape decks or microphones through your sound card:


1. Make sure the audio source is properly connected to the audio input of your computer. See [Connecting Your Stereo Equipment](#) for more information about how to connect your audio equipment.
2. Create a new an empty recording window by selecting *File | New...* or position the cursor where you want to insert recorded audio in an existing recording.
3. Select *Sound | Record...* or press Ctrl+R.
4. If you are recording to an empty editing window Acoustica needs to know what sample format you wish to use (see [Concepts of Digital Audio](#) for more information). The following dialog box appears:



The sample format dialog box in Acoustica

Please choose the desired recording format and click the button labelled *Ok*.

5. The Recording dialog box now opens:



The Recording dialog box


Now make sure that the correct input line is selected in the line in combo box (1). You can monitor the input level using the level meters (2) and, if needed, adjust the input level using the input level slider (3). The level meter should never be in the red

area in order to avoid clipping distortions.

6. Click the button labelled *Record* (4) to start the recording.
7. When you are done recording, click the button labelled *Keep* (5) to accept the recording.

4.2.1 Timer Record

The *timer record* feature allows you to start and stop recording after a certain period of time or depending on the presence of an input signal. To start timer record, click the button labelled *Timer Record* in the recording dialog. The following dialog box appears:



The Timer Record settings.


You can choose to start the recording immediately (after clicking the *Start Timer Record* button), at a certain time and date or when an input signal is present. The threshold value for the input signal detection can be defined using the *Silence Threshold* field at the bottom of the dialog.

The recording can also be stopped automatically, either after a certain period of silence

or after a certain period of time.

4.2.2 Advanced Recording Options

The recording dialog in Acoustica also offers some advanced settings:



The advanced recording options in the recording dialog

- **Remove DC Offset**

A DC offset (Direct Current offset) is present in the input signal when the audio signal isn't centered around the zero voltage line as it should be. The problem is quite common on low-end sound cards. DC offset are unwanted and harmful to the stereo equipment and it can lead to problems when processing the recording further. You can automatically remove the DC offset by enabling the option *Remove DC Offset*. Extremely low and inaudible frequency components (including the DC offset) are then filtered out of the signal.

- **Emulate phono preamplifier**


This option should only be enabled when recording from a record player that is connected directly to the input of the sound card without a phono preamplifier.

- **Listen to input (digital monitoring)**

You can listen to the signal being recorded (after DC offset and phono preamplifier processing, if enabled) by enabling this option. It is not recommended to leave this option on during the complete recording session, because it makes recording glitches more probable.

5 Audio Processing

In Acoustica, all the processing tools have some properties in common. The processing is performed on the selected region and the selected channels only. Furthermore, most tools offer a preset manager that allows you to save often used parameter settings for later use.



The Preset Manager found in most of the processing tools in Acoustica


To add a preset:

- Click the button labelled *More...*
- A drop down menu appears. Select *Add Preset...* from the menu.
- In the pop-up dialog, enter the name of the preset and click the button labelled *OK*.

Loading a preset is equally simple. Just select the preset from the drop-down list and the preset settings are loaded. User presets can be removed by clicking the button labelled *More...*, selecting *Remove Preset...* and selecting the preset you wish to remove.

You can bypass the effect processing by checking the check box labelled *Bypass transform* for a convenient A / B comparison.


The processing tools introduce some custom controls that you should get familiar with. The level slider is similar to the Windows track bar, but with some enhancements. The value range and the current value is always displayed. You can manually edit the value by pressing the space bar when the control is active or by clicking the value text below the level slider. An edit box pops up containing the current value. To change the value, enter a new value and press return. By pressing the Esc key the changes are discarded.



Examples of knobs (1) and level sliders (2).

The knob control is similar to the level slider, but it is round and is often used to save space in complex layouts. As with the level sliders, you can change the value by pressing the space bar or by clicking the value text below the knob.

A more complex custom control is the curve control which is used when a curve input is needed. The curve control allows the user to add, move or remove points. Straight lines between the points build the curve. You can add points by clicking the location where you want a new point to appear in the curve control. You can remove points by clicking the right mouse button over an existing point.



Examples of a curve edit control.


5.1 Manipulating Volume

The *Volume* menu contains several commands for manipulation the volume of a recording.

- [Adjusting the Volume](#)
- [Normalize](#)
- [Applying a Volume Curve](#)
- [Fading In or Out](#)
- [The Channel Mixer](#)

5.1.1 Adjusting the Volume

The most basic volume manipulation command is the *Adjust Volume...* command in the *Volume* menu. The only parameter is the volume change in decibel. For more information on the decibel unit, see [The Decibel Unit \(dB\)](#).




The Adjust Volume settings

5.1.2 Normalize

The *Normalize...* command in the *Volume* menu can be used to ensure a constants signal level in all your audio recordings. You can choose to normalize either the peak or the RMS level. After selecting your desired maximum peak or RMS output level in decibel, Acoustica analyses the selected region for the loudest peak or the overall RMS level. The


volume of the region is changed according to the selected level. If you set the normalize level to 0 dB and use peak level normalization, the loudest part will be the maximum level reproducible without signal distortion. For more information on the decibel unit, see [The Decibel Unit \(dB\)](#).



The Normalize dialog box

5.1.3 Applying a Volume Curve

You can apply a user drawn volume curve on the selected region by selecting *Draw Freehand Volume Curve...* from the *Volume* menu.




The Volume Curve settings

5.1.4 Fading In or Out

If you wish to create fade ins or fade outs, select *Fades...* from the *Volume* menu. You can select a fade curve from one of four mathematical functions from the *Fade function* drop-down list:

- Linear
- Logarithmic
- Exponential
- Sinusoidal


Select the direction of the fade using the *Fade in* or *Fade out* radio buttons. The resulting fade curve is visualized in the curve control.



The Volume Fade settings

5.1.5 The Channel Mixer

The channel mixer is a tool that works only on stereo recordings. The channel mixer mixes the content of the left and the right channels with a user defined weighting. The weightings are individually adjustable for each channel.




The Channel Mixer settings

5.2 Audio Effects

5.2.1 Dynamic Processor

A dynamic processor is used to alter the dynamic properties of the recording. To understand how a dynamic processor works, imagine a sound engineer trying to maintain an as steady volume level as possible while doing a recording. When the input level increases he pulls down the volume slider, and he pulls it up when the input level decreases. A dynamic processor does the same thing automatically, only with a much faster reaction time.




The Dynamic Processor settings

Settings

- An editable curve containing the output level as a function of the input level. By altering this curve you can change the dynamic characteristics of the recording to fit your needs.
- **Attack time**
The reaction time when the input level of the source material increases.
- **Release time**
The reaction time when the input level of the source material decreases.

5.2.2 Limiter

Limiters belong to the dynamic processing tools and ensure that the signal level doesn't exceed a user selectable boundary while minimizing any possible distortions. To achieve this, limiters introduce a certain latency, called look-ahead. The look-ahead ensures that the limiter can respond in time when the signal level suddenly rises. Many CD producers also use limiters to push the perceived volume to a maximum without introducing audible distortions.



The Limiter settings

Settings

- **Threshold**
All signals above the threshold level will be attenuated so that the threshold level is not exceeded.
- **Output Gain**
The output gain of the limiter which corresponds to the highest possible output signal level.
- **Release time knob**
You can use the release time knob to adjust the response time when the input level of the source material decreases. Longer release times will result in a smoother sound.
- **Look ahead knob**
You can adjust the number of milliseconds the limiter uses to determine its internal gain settings with the look-ahead knob. The limiter will have a latency equal to the look ahead time.

5.2.3 Echo

The echo effect adds delays or echoes to the selected region.




The Echo settings

Settings

- **Echo time**
- **Feedback**
The feedback percentage specifies the volume attenuation since the last delay interval.
- **Dry Level**
The amount of unprocessed signal in the output mix.
- **Delay Level**
The amount of processed signal in the output mix.

5.2.4 Reverb

The reverb simulates the reverberation effect of some natural surroundings.



The Reverb settings

Settings

- **Reverb program**

Select the reverberation program from the drop-down list that fit you needs. You can choose between *Small room*, *Medium room*, *Large room*, *Concert Hall 1*, *Concert Hall 2*, *Cathedral*, *Stadium* or *Plate* reverb. Only the Plate reverb needs further explanation. The plate reverb program simulates the sound of analog plate reverbs used frequently before digital reverbs were available.

- **Reverberation time**

The time before the reverb tail drops below 1 / 1000 of its original amplitude.

- **Reverb level**


The amount of processed signal in the output mix.

- **Dry out level**

The amount of unprocessed signal in the output mix.

5.2.5 Convolution Reverb

The convolution reverb can be used to apply recorded impulse responses from real acoustic spaces. The impulse response file can be of any format supported by Acoustica. Click the button *Load impulse response* to load an impulse response file. After loading an impulse response file, the signal level in dB over time is displayed in the curve edit control.




The settings page of the Convolution reverb

Settings

- **Dry level slider**
The amount of unprocessed signal in the output mix.
- **Reverb level slider**
The amount of dense reverberation in the output mix.
- **Volume curve**
You can modify the fade out characteristics of the reverb using the curve edit control.

5.2.6 Flanger

Flanger is an artificial effect. Flanger will occur when two sources playing the exactly same recording with a short time delay are mixed together. The result is that some frequencies are canceled, while others are amplified. Changing the time delay between the two sources will result in other frequencies being canceled or amplified.



The Flanger settings

Settings

- **Modulation depth**

Amplitude of the modulating function.

- **Modulation frequency**

Frequency of the modulation function. A higher modulation frequency will result in faster changes in the tone quality.

- **Feedback**

The feedback percentage specifies attenuation in the internal delayed feedback loop.

- **Stereo Flanger**

Toggles stereo or mono processing mode.

- **Dry Level**


The amount of unprocessed signal in the output mix.

- **Flanger Level**

The amount of processed signal in the output mix.

5.2.7 Chorus

Chorus adds warmth to recordings by dividing the audio source into several voices with a random vibrato. These artificially created voices are then mixed together.




The Chorus settings

Settings

- **Modulation depth**
Amplitude of the modulating functions.
- **Modulation frequency**
Frequency of the modulation functions. A higher modulation frequency will result in faster changes in the tone quality.
- **Feedback**
The feedback percentage specifies attenuation in the internal feedback loop.
- **Stereo Chorus**
Toggles stereo or mono processing mode.
- **Dry Level**
The amount of unprocessed signal in the output mix.
- **Chorus Level**
The amount of processed signal in the output mix.

5.2.8 Distortion

The *Distortion* effect distorts the recording using a simulation of an electric guitar amplifier.



The Distortion settings

Settings

- **Drive**
You can adjust the input gain of the distortion unit using the drive parameter.
- **Fuzz**
The fuzz parameter lets you adjust the fuzz level from 0 to 100%.
- **Output Level**
The output level lets you adjust the output gain from the distortion unit.
- **Lowpass cut-off**
The output of the distortion unit is processed with a low pass filter. You can adjust the cut-off frequency of the output filter.

5.2.9 Harmonizer

The harmonizer mixes several pitch shifted voices to create interesting harmonies. You can mix up to four pitch shifted voices. The often experienced "chipmunk" effect which occurs when transposing the human voice or musical instruments can be reduced using the *Maintain timbre* option. When *Maintain timbre* is checked, Acoustica creates a smooth spectral envelope estimation of the signal and whitens the signal before pitch shifting. The original smooth spectral envelope is applied after transposing and the original timbre is preserved.




The Harmonizer settings.

Settings

- **Activate**
Check this to activate the current voice.
- **Interval**
The musical interval to transpose. Use the radio buttons to set the transpose direction to *up* or *down*.
- **Fine tune**
With this slider you can fine tune the pitch shift factor in cents which are 1/100 of a semitone.
- **Volume**
Volume of the current voice in dB.
- **Pan**
Left / right panning of the current voice in percent.

5.2.10 Transpose

The transpose command allows you to transpose the content of the selected region with or without changing its length. When transposing without change of length, the Acoustica time stretching algorithm is used to compensate for the change of length normally occurring during pitch shifting.



The Transpose settings

Settings

- **Interval**

The musical interval to transpose. Use the radio buttons to set the transpose direction to up or down.

- **Fine tune**

With this slider you can fine tune the pitch shift factor in cents which are 1/100 of a semitone.

- **Maintain Duration**

Check this check box if you want the length of the section to be the same after pitch shifting.

- **Optimize for**

The inner settings of the time stretching algorithm are affected by choosing an optimization from one of the following: Speech, Music I or Music II, monophonic signals or percussive instruments only.

5.2.11 Time Stretching

The time stretch algorithm allows you to change the length of the recording without changing the perceived pitch. It is not physically possible to do this without some sort of distortion and the quality of these time correction algorithms lies in their ability to reduce the audible distortions. Acoustica uses a method that works well on monophonic signals like speech and single musical instruments as well as on polyphonic music. However, some artifacts occur on high expansion or compression rates like in all other time stretching software.



The Time Stretch settings

Settings

- **Percentage**

The time stretching factor in percent.

- **Optimize for**

The inner settings of the time stretching algorithm are affected by choosing an optimization from one of the following: *Speech*, *Music I* or *Music II*, *monophonic signals* or *percussive instruments only*.

- **Duration change**

Here you can enter the new length after time stretching.

- **Tempo change**

Here you can enter the original tempo in BPM and the target tempo after time stretching

5.2.12 Reverse

The reverse effect processes the selected region in such a manner that it will be played backwards.

5.3 Using Audio Plug-Ins


Acoustica 4 supports DirectX as well as VST plug-ins. Both formats have become widely used standards for audio processing plug-ins on the Windows platform. The menu *Plug-Ins* contains a list of the plug-ins currently installed on your computer. If you have installed a plug-in that does not appear in the list, please refresh the plug in list (see [Refreshing the Plug-in List](#)). Using DirectX or VST plug-ins is as easy as using the internal audio processing tools. You will see that previewing works exactly the same way as with the internal audio processing tools.

5.3.1 Refreshing the Plug-in List


If you have installed new DirectX or VST plug-ins on your computer that do not appear in the *Plug-Ins* menu you should refresh the menu by selecting *Plug-Ins | Refresh Plug-In List*. Acoustica then rescans the plug-ins on your computer and updates the menu.


5.3.2 Specifying VST Directories

VST plug-ins are not registered on your computer like DirectX plug-in, hence Acoustica needs to know where to find them. You can specify one or more directories to scan through.



The VST Directories dialog lets you specify one or more VST directories to scan through.

To add a new entry, click the add directory button []. You can edit a directory entry by double clicking with the left mouse button. Delete an entry by clicking the delete

button [].

5.4 Noise Reduction

Acoustica provides tools for removal of both stationary noise such as hiss and impulsive noise like clicks and pops. The frequency spectrum of stationary signals remain pretty constant over time. In other words, tape hiss, humming or other constant disturbances are removable using the Acoustica noise reduction system. The noise reduction is based on the spectral subtraction technique. This means that a spectrum of the noise present in the recording is needed. Acoustica can automatically estimate the noise profile or the spectrum of the noise can be obtained through analysis of a region containing noise only. Alternatively, the user can define the noise profile manually.

- [Automatic Noise Reduction](#)
- [Removing Noise with a Measured Profile](#)
- [Removing Noise with a User Drawn Profile](#)


Impulsive noise on the other hand consists of short unpredictable noise burst. It has become usual to define clicks as single noise bursts, whereas crackle is defined as a series of very short clicks with low amplitude. Acoustica is able to remove impulse noise due to the short duration of the noise bursts. Acoustica substitutes the recorded signal in the short period of time during the click with a signal estimated using the undistorted audio surrounding each clip.

You can remove clicks either automatically or manually:

- [Automated Click Removal](#)
- [Manual Click Removal](#)

5.4.1 Automatic Noise Reduction

The easiest way of removing stationary noise is to use the automatic noise reduction. Select *Enhancement | Automatic Noise Reduction...* Acoustica then performs a statistical analysis of recording in order to estimate the noise profile. This process might take a little while, depending on the length of your recording. After the analysis phase, the noise reduction window appear:



The Noise Reduction settings. The noise profile graph contains the result of the noise analysis.

There are two parameters you can adjust:


- Reduction factor scales the noise profile obtained in the analysis phase and allows you to remove more (positive values) or less (negative values) noise than the analysis algorithm detected.
- Max. attenuation allows you to adjust a maximum attenuation factor for each frequency component. This parameter is also referred to as noise floor. By leaving a certain noise floor, you can mask annoying artifacts from the noise reduction algorithm.

Initially, you cannot edit the noise profile graph after the noise analysis. If you want to edit the result:

- Click the button labelled *Edit Curve*
- The number of points in the curve is reduced and you can add, move or remove the curve points.

5.4.2 Removing Noise with a Measured Profile

If your recording contains pauses with pure noise without any other signal, the pause can be used to create a noise profile automatically. Select *Enhancement | Noise Analysis...* after selecting the region containing noise only. After the analysis phase, select *Enhancement | Noise Reduction...* The result of the analysis is automatically loaded in the profile graph.



The Noise Reduction settings. The noise profile graph contains the result of the noise analysis.


Apart from the analysis method, the noise reduction algorithm is exactly the same as with the [automatic noise reduction](#). Hence, the parameter settings have the same meaning.

5.4.3 Removing Noise with a User Drawn Profile

If no pauses are available for noise analysis you can draw a noise profile by hand. Select *Enhancement* | *Noise Reduction*. A curve editor shows up where you can manually enter a noise profile.

Note If you performed noise analysis in a previous editing step, you will need to reset the curve by selecting Reset from the preset list.

For tape hiss this method works quite well. The tape noise is more or less evenly distributed in the spectrum, thus a flat line should do the job. Finding the right threshold can be tricky, but after a bit of try and fail, good sounding settings should be possible to find.



The Noise Reduction settings with a manually drawn noise profile.

5.4.4 Automated Click Removal

The declicker is a specialized tool for removing impulsive noise such as clicks and crackle. It is based on two algorithms, one that targets rare but loud clicks, and one that targets very short and frequent clicks referred to as crackle.



The Declicker settings

Settings

- **Click Reduction**

Sets the sensitivity of the click filter. Higher reduction levels result in more click reduction.

- **Click length**

The maximal length of the clicks that are to be removed.

- **Crackle Reduction**

Sets the sensitivity of the crackle filter. Higher reduction levels result in more crackle reduction.

Optionally, clicks may be removed manually by selecting one single click and using the *Interpolate* command in the *Enhancement* menu.

5.4.5 Manual Click Removal


You can remove clicks manually by selecting the smallest region which fully includes the complete click and then select *Interpolate* from the *Enhancement* menu or press Ctrl+I. Acoustica substitutes the region with an estimate of the signal without the click.

Note Interpolation is only possible on short regions. If the selected region is too long, the Interpolate command is grayed out.

5.5 Enhancement Tools

5.5.1 Declipper

The declipper restores audio recordings distorted by clipping. Clipping occurs during recording when the recording level is too high and the highest peaks cannot be correctly recorded. The declipper substitutes such distorted peaks by an estimation of the signal curve using almost the same mathematical methods as the declicker when eliminating clicks.



The Declipper settings

The most important parameter of the declipper is the threshold level. The declipper will substitute all recorded peaks louder than the threshold value. Furthermore, the input gain of the declipper can be adjusted. That is helpful if the signal level is so high that the restored clips get louder the maximum signal level range.

Settings

- **Threshold**

All sample values louder than the threshold are substituted by a signal estimation.


- **Input gain**

The input gain is useful for adjusting the signal level before declipping.


5.5.2 Equalizer

Acoustica features a powerful six band parametric equalizer. Unlike a graphic equalizer, a parametric equalizer allows the user to select the center frequency of the bands. The equalizer in Acoustica also has variable bandwidths on each band.

The center frequency is specified in Hertz. Sound characters of the different frequencies are best discovered through experimentation. The bandwidth may be specified in octave bands. One octave band equals the frequency range of one octave on the piano keyboard. The bandwidth is the same parameter as the Q-factor found in some analog equipment. A higher Q-factor represents a narrower bandwidth.



The lower part of the equalizer dialog box is used to display the filter response curve (gain versus frequency). The filter response curve is calculated mathematically and is updated as the parameters are altered.



Settings

- **Frequency response**


The frequency response of the current equalizer settings is visualized. Each band is

visualized with a small circle with the number of the band. The currently active band is highlighted. You can activate band by clicking the circles representing each band. If you keep the mouse button down while moving the mouse cursor, you can change the gain and the center frequency of each band directly in the frequency response.

- **Frequency**
- **Gain**
- **Bandwidth**

5.5.3 High Frequency Rebirth

Dull and lifeless recordings may be a result of lost high frequency content. By using the *High Frequency Rebirth* tool (select *Enhancement* | *High Frequency Rebirth...*), you can add artificially created harmonics to brighten up the recording. Note that these are merely synthetic harmonics based on the low frequent content of the recording and this feature can only be used give the listener the impression of stronger harmonics.



The High Frequency Rebirth settings


Settings

- **Generate above**
Specifies the lower limit of the frequency band where harmonics should be synthesized.
- **Add content / Replace content**
If add content is selected, the original content in the synthesis frequency band is mixed with the synthesized harmonics. If you choose replace, Acoustica removes the original content before adding the synthesized harmonics.

- **Dry level**
The amount of unprocessed signal in the output mix.
- **High frequency level**
The amount of processed signal in the output mix.

5.5.4 Stereo Enhancer

The Stereo Enhancer enhances the stereo image by filtering the left and the right differently. The filters are designed to maintain mono compatibility.



The Stereo Enhancer settings

Settings


- **Stereo Depth**
Sets the amount of stereo enhancement from 0 (no enhancement) to 100% (maximum enhancement).

5.5.5 Remove DC Offset

Wrongly calibrated recording equipment may result in a signal that is not centered around zero as it should be. The *Remove DC Offset* tool (select *Enhancement* | *Remove DC Offset*) calculates the DC offset of the selected region and subtracts the offset if necessary.

5.5.6 Phono Filter

The phono filter emulates the effect of a phono preamplifier (deemphasis filter) or the opposite process applied when creating a master record (emphasis filter). In some cases, you can achieve better results from the declicker if you record an LP without the emulation of a phono preamplifier, apply the declicker and then apply the phono filter. You can post process any recording originating from an LP this way by first applying the emphasis filter, perform declicking and apply the deemphasis filter.



The Phono Filter settings

Settings


- **Emphasis or deemphasis mode**

Choose deemphasis mode if you have a recorded an LP record without phono preamplifier.

5.6 Converting the Sample Format

You can change the sample format of an audio recording by selecting *Sound | Convert Sample Format...* If you are not familiar with the terms sample rate or resolution, please read [Concepts of Digital Audio](#) before proceeding.


To convert the sample format of a recording, select *Sound | Convert Sample Format...* A dialog box appears where you can define the sample rate, resolution and the number of channels in the new sample format. Click the button labelled *Ok* when you are done.



The Convert Sample Format dialog box


5.7 Effect Chains

The effect chain editor allows you to link effects, processing tools, VST and DirectX plug-ins. The chains can be saved including the settings of the effects for later use. Furthermore, each element can easily be bypassed and the order of the elements changed using drag and drop.




The effect chain editor in Acoustica.

Adding Effects to the Chain

To add a new effect to the chain, click the add effect button []. A browser window appears where you can select the effect, plug-in or processing tool you want to add to the chain.



Removing Effects from the Chain

To remove an effect, select the effect you wish to remove and click the remove button [].

Editing the Effect Settings of an Element in the Chain

To open the effect settings window of an element in the chain, double click its entry in the list.



Playing the Audio Processed by the Effect Chain

You can play audio processed by the effect chain if you have an open editing window. Select the region you want to play in the editing window and click the play button []. The selection will be played looped. You can stop the playback by clicking the stop button [].

Bypassing an Element

You can bypass an element by clicking the checkmark left to the effect entry in the list.

Saving and Loading Effect Chains

You can store a complete effect chain including all parameter settings for later use. To store the effect chain, click the save button []. A standard file save dialog box appears where you can enter the file name. To open an effect, click the load chain button []


and select the file in the file browser.

6 Working with Audio CDs

You can create Audio CDs (see [Creating Audio CDs](#)) that you can play in normal CD players directly within Acoustica if you have a supported CD burner. Furthermore, Acoustica allows you to import audio tracks from existing CDs digitally and without quality loss for further editing or archiving on the computer (see [Importing Audio Tracks from CDs](#)).

6.1 Creating Audio CDs

Acoustica allows you to create audio CDs containing your edited recordings. The first step towards your own CD is to create a CD-Project by selecting *File | New | CD Project...* or by clicking the new button and select *CD Project...* from the drop-down list. The CD Project contains a list of the audio tracks to be written on the CD and an additional toolbar for commands related to the CD Project.



An empty CD Project window

The CD Project window contains a list of the audio tracks to be written to the audio CD.


You can add either

- existing audio files - or -

- [the content of an editing window](#)

as a separate tracks in the track list of the CD project.

6.1.1 Adding an Existing Audio File

You can add an existing audio file to the CD project by clicking the import audio file button () or using drag and drop from the Windows Explorer. If you click the import button, a standard file open dialog box appears (see [Loading Audio Files](#)) where you can selected the audio file or files you wish to add to the CD project.


6.1.2 Adding the Content of an Editing Window

The content (or parts of the content) of an editing window can be added as a track in the CD project without first creating an audio file:

1. Select the region in the editing window you wish to add as an audio track on the CD.
2. Click the left mouse button anywhere on the highlighted area and keep the mouse button down.
3. Move the mouse cursor to the track list in the CD project window.
4. Release the mouse button.

6.1.3 Burning the CD

When you are finished assembling your CD project, click the button labelled *Burn CD* from the toolbar of the CD Project window. The *CD Burner* dialog appears:



The CD burner dialog allows you to select a CD recording device, recording speed and the number of copies.

Insert a blank CD into the CD recording device. If you have several CD recording devices installed on your computer, make sure you choose the correct one from the *CD Recording Device* list. You can choose among different recording speeds and set the number of copies to burn. It is recommended to keep the *Enable buffer protection* option enabled, if supported (if not, the check box appears inactive). Click the button labelled *Burn* to start burning.


6.2 Importing Audio Tracks from CDs

It is possible to digitally import audio data from audio CDs with most CD-ROM readers. Acoustica will import title and artist information if available as CD-TEXT. If no CD-TEXT is available, you can perform an internet look-up in the FreeDB data base.

To import one or more audio tracks:

1. Select *Import Tracks from Audio CD...* from the *File* menu. If the CD doesn't contain any CD-TEXT information, you will be asked if you want Acoustica to look for artist and title information in the FreeDB data base on the Internet. If you choose no, the CD Track Extraction dialog box appears immediately. If you choose yes, there might be several entries matching your CD. Please choose the correct album from the list and choose OK.
2. If you have several CD-ROM devices installed, please make sure that the device that contains your source audio CD is selected in the CD-ROM Device drop-down list.
3. Select the track or the tracks you wish to import from the track list.

- Click the button labelled *Extract*.



The CD Track Extraction dialog box is shown. It features a table of tracks, an album information section, and a progress bar.

CD-ROM Device: SAMSUNG , DVD-ROM SD-616E vF501 (1:0:0)

#	Title	Track Type	Duration	Begin	End
1	Here With Me	Audio	00:04:15:400	00:00:00:000	00:04:15:400
2	Hunter	Audio	00:03:57:226	00:04:15:400	00:08:12:626
3	Don't Think Of Me	Audio	00:04:32:373	00:08:12:626	00:12:45:000
4	My Lover's Gone	Audio	00:04:27:893	00:12:45:000	00:17:12:893
5	All You Want	Audio	00:03:53:773	00:17:12:893	00:21:06:666
6	Thank You	Audio	00:03:38:360	00:21:06:666	00:24:45:026
7	Honestly OK	Audio	00:04:38:773	00:24:45:026	00:29:23:800
8	Slide	Audio	00:04:52:200	00:29:23:800	00:34:16:000
9	Isobel	Audio	00:03:54:093	00:34:16:000	00:38:10:093
10	I'm No Angel	Audio	00:03:55:600	00:38:10:093	00:42:05:693
11	My Life	Audio	00:03:09:706	00:42:05:693	00:45:15:400
12	Take My Hand	Audio	00:06:42:733	00:45:15:400	00:51:58:133

Album Information

Album title: No Angel

Artist: Dido

Genre: Pop

Year: 1999

Progress

Current Track: Idle

Extract Cancel

The CD Track Extraction dialog box

The imported audio tracks appear as separate editing windows in the Acoustica workspace.

Adding Track Titles and Album Information Manually


If there is no FreeDB entry available for your CD you want to modify the information, you can do this manually in the CD Track Extraction dialog. To rename a track title, double click the track entry in the list or press F2. A dialog box appears where you can enter the new track name.

The album information can be changed directly with the edit boxes in the *Album Information* group box.

Note You can listen to the content of a track by clicking the button labelled *Preview*

7 Using the Cleaning Wizard

If you are new to digital audio recording, the Cleaning Wizard simplifies LP or cassette to CD transfers by guiding you through all the steps from recordings, track splitting, restoration and CD burning. To open the Cleaning Wizard, select *File | Cleaning Wizard...* and the following window appears:



The Cleaning Wizard window


Note The Cleaning Wizard leads you step by step through the process of transferring your analog audio to CD. However, if you can choose to go back to an earlier step or skip one or more steps at any time by clicking at the Import, Restoration or Export tabs at the top of the wizard.

7.1 The Import Page

The import page is the first step in the Cleaning Wizard. From here you can choose to record an LP, record a cassette, import an audio file or get help about connecting your audio equipment. Click on one of the options to proceed.

7.1.1 Record Audio

If you choose to record from either LP or cassette the Cleaning Wizard will proceed to the recording page:



The recording page in Acoustica 4.

The input level meter (2) shows the current input level. If you have connected your audio equipment and started playback, the meter should show a constantly changing input level. If the level is low and not changing, there is probably something wrong with the connection or the wrong input line is selected. You can usually choose between several different input lines, like *microphone* or *line in*. The Cleaning Wizard tries to set *Line In* as input line automatically, however, you should check the input line setting (1) before proceeding. If you are uncertain, please try through the options and see if there is any response on the input level meter (2).

Recording Step by Step


1. Make sure your audio equipment is properly connected to your computer
2. Check that the input line (1) is correctly set. In most cases, the line input should be set to *Line In*
3. Check that the input level is in the correct range. You can easily check the input level using input level meter (2). You can adjust the input level using the input level slider (3). The meter should never go up to 0 dB, otherwise digital clipping will be introduced. Check with the loudest part of the record or cassette tape you are

- recording that the input level meter doesn't go higher than about -6 dB.
4. Click the button labelled Record (4) to start the recording.
 5. Press play on your tape deck or record player.
 6. Press the Next button in the lower right part of the Cleaning Wizard when you have recorded the whole record or cassette tape.

Note The recording page has several advanced features not mentioned here. Please see the chapter [Recording through the Sound Card](#) for more details about the advanced features such as timer record, digital monitoring and DC offset correction.

7.1.2 Import Files

If you choose to import an existing audio file, a file browser window appears where you can select the audio file you want to open.




The File Import page in the Cleaning Wizard.

To import an audio file, please do the following:

1. Choose the folder in which your file is located from the Look in drop-down list.
2. Click the audio file you wish to open and click the button labelled Next.

7.2 The Restoration Page

The *Restoration Page* allows you to adjust the settings of the audio restoration tools and split the recording into several tracks.



The Restoration Page contains a waveform view of the recording and list of the tracks, as well as audio restoration and processing options.

1. The waveform view shows you a graphical representation of the recording. Tracks are indicated with a different color.
2. The transport bar allows you to control playback.
3. The track list shows you the tracks defined. The Cleaning Wizard automatically suggests tracks, however, you can easily add, move or remove track markers.
4. The audio restoration tools, declicker, decrackler, declipper and denoiser. You can adjust the amount of restoration using the sliders and activate or deactivate a tool using the on / off buttons.
5. You can add further effects and processing tools, like equalizing or reverb. You can choose among all the internal tools and effects as well as VST and DirectX plug-ins.

7.2.1 Track Splitting

The Cleaning Wizard automatically searches for pauses and suggests tracks when recording or importing audio files. However, if the recording is very noise or tracks are blended seamlessly into each other, the tracks suggested by the Cleaning Wizard might not be identical to the original tracks on the source record or cassette.

Changing the Region of an Existing Track

1. Move the mouse cursor to the beginning or the ending of a track. The mouse cursor turns into a left-right arrow.

2. Keep the left mouse button pressed while moving the mouse cursor to the new position.
3. Release the mouse button.

Adding a track

1. Move the mouse cursor the beginning of the track you want to add in the waveform view.
2. Keep the left mouse button pressed while moving the mouse cursor to the end of the track.
3. Release the mouse button.
4. Click the button labelled *Add Track*.

Removing a Track

1. Click the track you want to remove in the track list.
2. Press the *Delete* key on your keyboard.


Renaming a Track

1. Click the track you want to rename in the track list.
2. Wait more than two seconds without moving the mouse cursor or press the F2 key on your keyboard.
3. The entry in the track list turns into an edit box. Enter the new name of the track.

7.2.2 Restoration

There are four restoration tools integrated into the Cleaning Wizard:

- **Declicker**
Removes loud clicks and pops.
- **Decrackler**
Removes short but frequent clicks, referred to as crackle.
- **Declipper**
Restores recordings that suffer from analog or digital clipping.
- **Denoiser**
Removes static noise like tape hiss.



The restoration tools in the Cleaning Wizard

You can adjust the effect of each tool by moving the sliders in the range from 0% (no effect) to 100% (full effect). Furthermore, each tool can be activated or deactivated by clicking the on / off button left to the slider.

Playing Restored Tracks

The restoration tools in the Cleaning Wizard are processed in real time during playback so that you can listen to the effect of different restoration settings during playback. You can control the playback from the transport buttons in the Restoration Page:



The transport button bar in the Restoration Page gives you full control over the audio playback.

Start the playback by clicking the play button (1). The playback will start from the current cursor position in the waveform. You can also use the play all button (2) to play the complete recording. Stop the playback by clicking the stop button (3).

7.2.3 Further Editing and Processing

The Restoration Page in the Cleaning Wizard also lets you add further effects (or processing tools) to the recording. You can choose among all the internal effects as well as VST or DirectX effects. When you play the recording in the Restoration Page, the effects are processed in real time so that you can check the results immediately.

Adding Further Effects

1. Click the button labelled *Add Effect* below the additional effects list.
2. Select the effect you want to add to the effects list.

Editing the Effect Parameters

1. Double click the effect in the additional effects list.
2. The effect settings page is shown.
3. Make your changes and close the window when done.

Removing an Effect from the List


1. Click the effect you want to remove.
2. Press the *Delete* button.

7.3 The Export Page

You can export your cleaned up tracks to audio files or burn them directly on a CD. Please choose one of the two.

7.3.1 Burn a CD

If you choose to burn a CD, the *CD Burner* dialog appears:




The CD burner dialog allows you to select a CD recording device, recording speed and the number of copies.

Insert a blank CD into the CD recording device. If you have several CD recording devices installed on your computer, make sure you choose the correct one from the *CD Recording Device* list. You can choose among different recording speeds and set the number of copies to burn. It is recommended to keep the *Enable buffer protection* option enabled, if supported (if not, the check box appears inactive). Click the button labelled *Burn* to start burning.

7.3.2 Export to Audio Files

If you choose to export your tracks to audio files, the *File Export Page* appears:




The File Export Page in the Cleaning Wizard

You can choose a destination directory for your tracks (1), an album name (2) and the file format of the exported tracks (3). During the export, an directory will be created with the album name and the tracks are written to audio files with the name of the tracks within the album directory.

8 Using the Batch Processing Wizard

The Batch Processing Wizard in Acoustica 4 allows you to convert and processed a large number of files without user interaction. Even complete directory stuctures can be processed at once. To start the Batch Processing Wizard, select *File | Batch Processing Wizard...*, and a the Batch Processing Wizard appears on your screen as depicted below.



The Batch Processing Wizard window.

8.1 Adding Source Files


The first step of the Batch Processing Wizard is to add the source files. The most straight forward way to add files is to click the button labelled "Add files". A standard file open dialog opens where you can browse and choose one or more files to open. You can repeat this procedure if you wish to add files from several folders.

The source files can be arranged in folders or you can choose to import complete folder structures.

Note You can listen to the imported files by clicking the preview button below the file list. Click the stop button to stop previewing.

8.1.1 Importing Folders

To import the complete content of a folder, click the button labelled "Add folder". The following dialog box appears:



The import folder dialog box allows you to import complete folder structures.

Use the folder browser to select the folder you wish to import. You can choose to import only the content of the selected folder or the whole folder structure by clicking the check box "Include subdirectories".

The "Import files of type" drop down list lets you reduce the files to all known file formats or a specific file format only.

8.1.2 Creating Folders


You can also create target folder structures manually by clicking the "Create folder" button. A dialog box appears where you can enter the name of the new folder.

8.1.3 Removing an Item

You can remove an item (file or folder) by selecting the item and clicking the button labelled "Remove item".

8.2 The Target Files Page

When you have added all the files you wish to convert or process you can proceed to the "Target Files" page by clicking the "Next" button or the "Target Files" tab. The following page appears:




The Target Files page of the Batch Processing Wizard.

Note You can choose to start processing from the Target Files page any time by clicking the button labelled "Start" below the Target Files page.

8.2.1 Adding Processing Tools

The Batch Processing Wizard lets you process the files with internal tools and effects as well as VST and DirectX plug-ins. The "Processing Tools & Effects" section of the Target Files page contains a list of the processing tools that are to be used when processing the files.

To add a processing tool, click the button labelled "Add". The "Processing Tools Browser" appears from which you can select the effect, processing tool or plug-in you wish to add to the list.



The Processing Tools Browser lets you select an internal processing tool or a plug-in.

When you have selected the processing tool, click the button labelled "Add".

You can change the parameter settings of a processing tool by clicking the "Edit" button or by double clicking an item in the Processing Tools & Effects list.

To remove a processing tool from the list, click the processing tool to highlight it and click the "Remove" button.

Loading Effect Chain Files

The Batch Processing Wizard is able to import complete effect chains created by the effect chainer in Acoustica or the Acon Digital Media EffectChainer. To load an effect chain file, click the "Load chain" button. A standard file open dialog box appears where you can select the effect chain file you wish to load.

8.2.2 Defining File and Sample Format

The "File & Sample Format" section of the Target Files page lets you select an output file format. To set the output file format you can simply choose the output format from the file type drop-down list. If the file format offers custom parameters settings, like encoding bitrate for mp3 files, you can edit these settings by clicking the button labelled "Options" next to the file type drop-down list.

Furthermore, you can define the sample rate, number of channels and resolution of the

target files. If you convert high resolution audio files to a lower resolution, you can optionally apply dithering and noise shaping.

8.2.3 Specifying the Target Folder


The last section of the Target Files page lets you select an output folder. You can either enter a folder path in the edit box or click the button labelled "Browse" to select a folder from the folder structure of your computer.

9 Audio Analysis

Acoustica features a range of tools that allows you to study your recorded material in the time domain (see [Time Domain](#)), frequency domain (see [Frequency Domain](#)) or a combination of these (see [Combining Time and Frequency](#)).

9.1 Time Domain

The normal wave plot shown when making a recording in Acoustica is a time domain representation of the signal. When recording, Acoustica has taken samples of the signal at certain intervals, quantized them, and stored them as series of digitized values. The wave plot is the result of drawing these samples on the screen with the time evolving along the horizontal axis.




A plot of a signal represented in the time domain

9.2 Frequency Domain

All natural sounds can be described as an infinite sum of sine functions. The frequency of a sine function is related to what we sense as pitch. Our ears are not able to hear frequencies above 20kHz (a sine function with 20 thousand completed wavelengths within one second), so the mentioned infinite sum turns into a finite sum which is


possible to handle on a computer. The signal in the frequency domain is represented through the weight of each sine function needed to recreate the signal, rather than the sampled values from the time series. These weights are visualized in Acoustica by selecting *Analysis | Spectrum Analyzer*.



A plot of a signal represented in the frequency domain.

9.3 Combining Time and Frequency

We have a tool for examining the frequency content (the spectrum) of our recording and we have the normal wave plots for examining how our recording evolves over time. Is there a possibility to combine these features, in order to study how the frequency content evolves over a period of time? Actually, Acoustica features two ways of displaying so called time-frequency plots. The spectrogram and the wavelet transform (based on the Morlet class of wavelets for the advanced reader). They differ mainly in the frequency scale. The spectrogram has a linear frequency scale whereas the wavelet transform has a logarithmic frequency scale.



A spectrogram generated by Acoustica. The vertical axis represents the frequency, the horizontal represents time.

You can adjust the resolution and the color representation in both the spectrogram and the wavelet transform in the Preferences dialog box (see [Changing the Preferences](#)).


10 Preferences and Device Settings

10.1 Device Settings

Window's multimedia system allows several different audio cards being installed at the same time. You can select which sound card to use by selecting *Device Settings...* from the *Options* menu. Choose input and output devices from the drop-down lists in the device settings dialog to change the current configuration and click the button labelled *Ok*.

10.2 Changing the Preferences

You can set your personal preferences with the command *Preferences...* in the *Options* menu.



The Preferences dialog box


The preferences are organized in different pages. Only one page is shown at a time and you can show another page by clicking the tabs in the upper part of the dialog box. The following pages are available:

- Directories
- Spectrogram

- Wavelet Transform

10.2.1 The Directories Page

The *Directories* page contains only one setting, the directory for all temporary files created by Acoustica. You should set this directory path to a directory on a fast hard disk with sufficient free space. Acoustica works extensively with temporary files and the speed of the programs depends to a large degree on the speed of the hard disk where the temporary files are situated.



The directories preferences page

Index

- A -

Adding Audio Files as CD Tracks	58
Adding Processing Tools to the Batch Processing Wizard	71
Adding source files to the Batch Processing Wizard	69
Adding the Content of an Editing Window to a CD Project	58
Audio Analysis	73
<i>combining time and frequency</i>	74
<i>frequency domain</i>	73
<i>time domain</i>	73
Audio CDs	
<i>adding files as tracks</i>	58
<i>adding the content of an editing window</i>	58
<i>creating</i>	57
<i>importing audio tracks from</i>	59
<i>working with</i>	57
Audio editing window	5
Audio files	
<i>loading</i>	7
<i>saving</i>	7
Audio Processing	28

- B -

Batch Processing Wizard	68
<i>adding processing tools</i>	71
<i>adding source files</i>	69
<i>creating folders</i>	70
<i>file and sample format</i>	72
<i>importing folders</i>	69
<i>removing items</i>	70
<i>Source Files page</i>	69
<i>Target Files page</i>	71
<i>target folder</i>	73

- C -

CD project	5
Chains of Effects	56
Channel Mixer	32
Channels	
<i>selecting</i>	8
Chorus	39

Clipboard	10
Converting	
<i>sample format</i>	55
Converting the Sample Format	55
Convolution Reverb	37
Copy	10
Creating folders in the Batch Processing Wizard	70
Cut	10

- D -

DC Offset	
<i>removing</i>	54
Decibel (dB)	25
Declicker	49
Delay	36
Device Settings	75
Digital Audio	23
<i>decibel (dB)</i>	25
<i>quantisation</i>	24
<i>sampling</i>	24
DirectX	
<i>refreshing the plug-in list</i>	45
<i>using plug-ins</i>	45
Distortion	40
Drag and drop	
<i>copying</i>	9
<i>moving</i>	9
Dynamic Processor	33

- E -

Editing	
<i>basic</i>	5
<i>using drag and drop</i>	9
<i>using the clipboard</i>	10
Effect Chains	56
Effects	
<i>chorus</i>	39
<i>convolution reverb</i>	37
<i>delay</i>	36
<i>distortion</i>	40
<i>dynamic processor</i>	33
<i>flanger</i>	38
<i>harmonizer</i>	41
<i>reverb</i>	37
<i>reverse</i>	45
<i>Time Stretching</i>	44

Effects		Playing	7
<i>Transpose</i>	42	Playing a region in a loop	7
Enhancement		Plug-Ins	45
<i>Equalizer</i>	51	Preferences	
<i>high frequency rebirth</i>	53	<i>changing</i>	75
<i>removing the DC offset</i>	54	<i>directories</i>	76
Equalizer	51	Processing tools	
- F -		<i>adding to the Batch Processing Wizard</i>	71
Fades	32	- Q -	
Flanger	38	Quantisation	24
Frequency Domain	73	- R -	
- H -		Recording	23
Harmonizer	41	Recording Audio	25
High Frequency Rebirth	53	Refreshing the DirectX plug-in list	45
- I -		Region	
Importing folders to the Batch Processing Wizard	69	<i>playing</i>	7
Impulse response	37	<i>playing in a loop</i>	7
Introduction	4	<i>selecting</i>	8
<i>Requirements</i>	5	Removing items in the Batch Processing Wizard	70
<i>What is new in Acoustica 4.1</i>	4	Removing the DC offset	54
- L -		Requirements	5
Loading an audio file	7	Reverb	37
Looped playback	7	Reverse	45
Loops		- S -	
<i>adding loops for MIDI samplers</i>	13	Sample format	
- M -		<i>converting</i>	55
Manual Click Removal	50	Samplers	
MIDI samplers		<i>adding loops for MIDI samplers</i>	13
<i>adding loops</i>	13	Sampling	24
- N -		Saving an audio file	7
Noise Reduction	46	Scrollbar	8
<i>clicks and pops</i>	49	Scrolling	8
<i>manual click removal</i>	50	Selecting a region	8
<i>using a measured noise profile</i>	47	Selecting the active channels	8
<i>with user defined profile</i>	48	Source Files in the Batch Processing Wizard	69
Normalize	30	Spectrogram	74
- P -		- T -	
Paste	10	Time Domain	73
		Time Stretching	44

Transpose	42
-----------	----

- V -

Volume	
--------	--

<i>adjusting</i>	30
------------------	----

<i>applying a volume curve</i>	31
--------------------------------	----

<i>channel mixer</i>	32
----------------------	----

<i>fade ins and fade outs</i>	32
-------------------------------	----

<i>normalize</i>	30
------------------	----

Volume manipulation	30
---------------------	----

- W -

Waveform visualisation	5
------------------------	---

Wavelet	74
---------	----

Workspace	5
-----------	---

- Z -

Zooming in or out	8
-------------------	---